



























Corded Telephones

ITEM NUMBER	AMER-JV35	AMER-P300	AMER-VCOP	AMER-XL30	AMER-XL40	AMER-XL50	CL-C200	CL-C2210	CL-C320
									
Amplify/Boost Button	X	X	X	X	X	X	X	X	X
Amplify Override	X		X	X	X	X	X	X	X
Answering Machine			X						X
Backlit Keypad			X		X	X	X	X	X
Battery Backup	X		X		X	X			
Caller ID								X	
Incoming Amplification	37dB	20dB	30dB	30dB	43dB	60dB	26dB	50dB	30dB
Jack A) Neckloop/Headphone (listening) B) Headset (listen/talk) C) Shaker option	A) 3.5 mm	A) 3.5 mm	A) 3.5 mm	A) 3.5 mm	A) 3.5 mm	A) 3.5 mm B) 3.5 mm		A) 3.5 mm B) 2.5 mm C) 3.5 mm	A) 3.5 mm B) 2.5 mm
Large Buttons	X	X	X	X	X	X	X		X
Loud Ringer	X	X	X	X	X	X	X	X	X
Outgoing Amplification				15dB					
Ring Flasher	X	X	X	X	X	X	X	X	X
Speed Dial	10	9	10	12	12	11		2	13
Separate Tone Control	X		X	X	X	X		X	
Speakerphone									
Other Features: DCP = Digital Clarity Power	Braille	Photo buttons	Printer port					DCP; lamp/ vibrator opt	
HEADSETS * No boom mic (under-the-chin mic) ** Wireless									
CLA7 Neckloop								X	X
GN-GN9120**	X	X	X	X	X	X		X	X
HAT-SHDST								X	X
HT-900HS								X	X
Plantronics M130/M170/M220								X	X
SKC-S12	X	X	X	X	X	X		X	X
TD-TCA86								X	X










Corded Telephones

ITEM NUMBER	CL-C510	CL-P400	HC-AEC	HC-CST25	HC-RE40	HC-RE50	KM-EQ40	KM-SP50
								coming soon
Amplify/Boost Button	X	X	X		X	X	X	X
Amplify Override	X	X	X				X	X
Answering Machine								
Backlit Keypad	X			X	X	X		X
Battery Backup		X	X					X
Caller ID	X		X	X				X
Incoming Amplification	30dB	26dB	50dB	25dB	40dB	50dB	40dB	50dB
Jack A) Neckloop/Headphone (listening) B) Headset (listen/talk) C) Shaker option	A) 3.5 mm B) 2.5 mm	A) 3.5 mm	A) 3.5 mm B) 2.5 mm C) 3.5 mm		A) 3.5 mm	A) 3.5mm		
Large Buttons		X	X	X	X	X	X	X
Loud Ringer	X	X	X	X	X	X	X	
Outgoing Amplification			12dB					
Ring Flasher	X	X	X	X	X	X	X	X
Speed Dial	3	9	8		13	13	13	12
Separate Tone Control	X		X		X	X	X	X
Speakerphone			X	X	X	X		X
Other Features: DCP = Digital Clarity Power		Photo buttons	Remote emergency connect	7.4" display	Hold music	Hold music	3 frequencies	2 way speakerphone
HEADSETS * No boom mic (under-the-chin mic) ** Wireless								
CLA7 Neckloop	X		X					
GN-GN9120**	X	X	X		X	X		
HAT-SHDST	X		X					
HT-900HS	X		X					
Plantronics M130/M170/M220	X		X					
SKC-S12	X	X	X		X	X		
TD-TCA86	X		X					

Corded Telephones

ITEM NUMBER	KM-SPS	TD-CEZAI998	UTI-CT	UTI-CTPLUS	WE-1100	WE-CLAR	WS-TEL030	WS-TEL040	GE-PHONE3	GE-PHONE4
										
Amplify/Boost Button	X	X	X	X	X	X		X	X	X
Amplify Override					X	X			X	X
Answering Machine		X								
Backlit Keypad	X	X								
Battery Backup	X			X					X	X
Caller ID		X								X
Incoming Amplification	50dB		35dB	50dB	33dB	26dB	25dB	55dB	40dB	40dB
Jack A) Neckloop/Headphone (listening) B) Headset (listen/talk) C) Shaker option	A) 3.5 mm	B) 2.5 mm	A) 3.5 mm	A) 3.5 mm	A) 3.5 mm	A) 3.5 mm		A) 3.5mm	A) 3.5 mm C) 2.5 mm	A) 3.5 mm C) 2.5 mm
Large Buttons	X	X	X	X	X	X	X	X	X	X
Loud Ringer	X		X	X	X	X	X	X	X	X
Outgoing Amplification			12dB	12dB						
Ring Flasher	X	X	X	X	X	X	X	X	X	X
Speed Dial	13	15	13	13	11	11			7	13
Separate Tone Control	X		X	X	X	X		X	X	X
Speakerphone	X	X		X					X	X
Other Features: DCP = Digital Clarity Power		Corded and cordless				Sound equalizer				
HEADSETS * No boom mic (under-the-chin mic) ** Wireless										
CLA7 Neckloop	X		X		X					
GN-GN9120**	X	X	X	X	X	X	X	X		
HAT-SHDST	X		X		X					
HT-900HS	X		X		X					
Plantronics M130/M170/M220	X		X		X					
SKC-S12	X	X	X	X	X	X	X	X		
TD-TCA86	X		X		X					

Corded Telephones

ITEM NUMBER	HC-HD30P	HC-HD40P	HC-HD60	HC-HD60J	HC-ST50	HC-ST150	HC-ST250	FC-PICPHONE	FC-SOSPHONE
									
Amplify/Boost Button					X				
Amplify Override									
Answering Machine									
Backlit Keypad									
Battery Backup									
Caller ID					X	X	X		X
Incoming Amplification	30dB	30dB	55dB	55dB	52dB	52dB	52dB	40dB	40dB
Jack A) Neckloop/Headphone (listening) B) Headset (listen/talk) C) Shaker option	A) 3.5 mm	A) 3.5 mm	A) 3.5 mm	A) 3.5 mm	A) 3.5 mm	B) 2.5 mm	B) 2.5 mm		
Large Buttons	X	X	X	X	X				
Loud Ringer	90dB	90dB	95dB	95dB	85dB				90dB
Outgoing Amplification									
Ring Flasher	X	X	X	X	X			X	X
Speed Dial	9	9	12	13	3	7	4	10	2
Separate Tone Control	X	X	X	X	X				X
Speakerphone					X	X	X		X
Other Features: DCP = Digital Clarity Power							2-lines		
HEADSETS * No boom mic (under-the-chin mic) ** Wireless									
CLA7 Neckloop									
GN-GN9120**									
HAT-SHDST									
HT-900HS									
Plantronics M130/M170/M220									
SKC-S12									
TD-TCA86									

Corded Telephones

ITEM NUMBER	HC-AMPLI200	HC-AMPLI500B	HC-AMPLI600	HC-AMPLIVOICE50	HC-AMPLI1100B			
								
Amplify/Boost Button			X					
Amplify Override			X		X			
Answering Machine								
Backlit Keypad								
Battery Backup	X			X				
Caller ID		X	X	X				
Incoming Amplification	35dB	50dB	50dB	12dB	30dB			
Jack A) Neckloop/Headphone (listening) B) Headset (listen/talk) C) Shaker option		A) 3.5 mm B) 2.5 mm	A) 3.5 mm B) 2.5 mm					
Large Buttons		X		X				
Loud Ringer		95dB	95dB					
Outgoing Amplification			12dB					
Ring Flasher	X	X	X	X	X			
Speed Dial		11		3	12			
Separate Tone Control	X	X	X		X			
Speakerphone	X	X	X	X				
Other Features: DCP = Digital Clarity Power								
HEADSETS * No boom mic (under-the-chin mic) ** Wireless								
CLA7 Neckloop								
GN-GN9120**								
HAT-SHDST								
HT-900HS								
Plantronics M130/M170/M220								
SKC-S12								
TD-TCA86								